
Descal/Decalcify Procedure for One Touch/Aulika Focus Coffee Machine

The machine is pre-programmed to descale or decalcify at regular intervals. You will receive a message on the display screen telling you when to descale. This is an important process that must be carried out when required. Failure to do so can damage the machine and affect the taste of the coffee.

Before starting the procedure you will need the descaling solution and two empty containers to fit under the hot water spout and the autofrother/cappuccinatore. The screen display will prompt you to complete each step (also outlined below). This process takes approximately 40 minutes and you will need to be nearby to refill the water tank when prompted and to empty the containers underneath the hot water spout and cappuccinatore as they become full to avoid overflow.

1. "Calc Clean" will show on display and upon next startup the message "DESCALING NEEDED DESCALE?" will appear.
2. Press "OK"
3. "START DESCALING" will appear. Press "OK"
4. "FILL TANK WITH DESCALING SOLUTION" will appear. Add one measure cap of descale solution and fill tank with water to level indicated by "Calc Clean"
5. Place tank back on machine and press "OK"
6. "EMPTY DRIP TRAY" – Empty drip tray, reinsert and press "OK"
7. "PLACE A CONTAINER UNDER MILK & HOT WATER SPOUTS" – Once done Press "OK"
8. "DESCALING STEP 1/2" – This will take between 5 – 10 Min
9. "RINSE TANK & FILL WITH FRESH WATER" – this time fill water tank to "MAX" level & Press "OK"
10. "DESCALING STEP 2"
11. "REFILL WATER TANK" – Refill tank, replace and machine is ready for use.

Please call us on 1300 12 02 62 if you need any assistance.